

Skivhiss

Drywall lifter



Item No:
498030



Kontaktinformation

Verktysboden Erflux AB
Källbäckstrydgatan 1
SE-507 42 Borås
Telefon: 033-202650
Mejl: info@verktysboden.se

Miljöskydd / Skrotning

Återvinn oönskat material, släng det inte bland hushållssoporna. Alla maskiner, tillbehör och förpackningar skall sorteras och lämnas till en återvinningscentral och där kasseras på ett miljövänligt sätt.



Specifikationer

Max. skivstorlek.....1220x4880mm
Max vikt.....70 kg
Max lyfthöjd.....3150mm
Last höjd.....1800mm
NW/GW.....27/29 kg

Uppackning

När produkten har packats upp, kontrollera att alla delar är inkluderade och att inga delar är synbart defekta.

Miljömässiga krav för installation


Platsen som den skall monteras på måste uppfylla följande:

- Plant, horisontellt och stabilt golv, helst i betong eller belagt med klinker.
- Tillräckligt utrymme måste finnas omkring maskinen för att underlätta användningen.
- Ordentlig belysning.
- På denna yta får ingen utomstående person befinna sig och inga föremål som kan utgöra en


Montering

Din skivhiss kräver en enkel montering före användning. Det är viktigt att du läser hela manualen för att bekanta sig med produkten innan du använder skivhissen. Innan du monterar skivhissen skall du vara säker på att du har alla delar som beskrivs i sprängskissen. Sprängskissen hittar du i slutet av den här manualen.

1. Skruva loss muttrarna (7#) från de 5 hjulen (6#). För igenom gängen på hjulen genom hålen som är förborrade i armarna (2#). Skruva tillbaka muttrarna och dra åt ordentligt.



2. För in det förmonterade teleskopröret (8#) i hålet i foten (1#).




3. Skruva ihop lyftplattformen.

Börja med att skruva loss skruvarna (22#) från profilröret (19#). Skruva fast sidorören (20#) i profilröret (19#) med hjälp av skruvarna (22#).



4. Montera fast lyftplattformen.

Ta loss låssprint (21#) och för in lyftplattformen (19#) i fyrkantsrör (9#). Sätt tillbaka låssprint (21#). Kontrollera så att låssprinten låst i spåret i lyftplattformen (19#).




Användning

1. Lägg skivan på lyftplattformen. Se till så att den är så centrerad som möjligt.
2. Flytta skivhissen så den står under platsen där skivan skall monteras i taket.
3. Snurra manöverhjulet medurs (18#) för att hissa skivan mot taket. Skivhissen är utrustad med en spärr som går i varje centimeter när du höjer lyftplattformen. Om manöverhjulet av misstag skulle släppas under upphissning så går spärren in och stoppar skivan från att falla ned.
4. När skivan är hissad till önskad höjd, släpp manöverhjulet försiktigt och se till så att spärren går i.
5. Skruva fast skivan i taket.
6. Sänk lyftplattformen genom att trycka

säkerhetsspärren uppåt och snurra manöverhjulet moturs. Släpp inte hjulet så att lyftplattformen rasar ned och skadar teleskopröret.

Underhåll

1. Smörj kedjan, kedjehjulet och det inre teleskopröret med fett.
2. Smörj kullagret till manöverhjulet och fotens bussning regelbundet med smörjolja.
3. Förvara skivhissen på i en torr miljö.



Del nr	Beskrivning	Antal
1	Bas	1
2	Stödarm	5
3	Ändkåpa	9
4	Bult M10x45	5
5	Mutter M10	5
6	Hjul	5
7	Mutter M12	6
8	Yttre röret	1
9	Inre röret	1
10	Kedja	1
11	Skruv	6
12	Kugghjul	1
13	Kugghjulsaxel	1
14	Axelhylsa	2
15	Säkerhetsbroms	1
16	Bult M8x60	2
17	Mutter M8	3
18	Handtag	1
19	Översta pelaren	1
20	Sidorör	1
21	Fjäder	1
22	Bult M6x35	4
23	Stift 6mm	1
24	Bult M8x16	2
25	Fjäderstöd	1
26	Fjäder	1
27	Bult M8x30	1
28	Insexnyckel 8	1
29	Insexnyckel 6	1
30	Insexnyckel 5	1
31	Bricka 12	5
32	Bricka 10	10
33	Bricka 6	4
34	Bricka 16	1

EG FÖRSÄKRAN OM ÖVERENSSTÄMMELSE

Maskindirektivet (MD) 2006/42/EC

ORIGINAL DEKLARATION

Vi, tillverkaren

Företag: Verktysboden Erfilux AB
Adress: Källbäckstrydsgatan 1, SE-507 42 Borås, Sweden
Telefon: +46-33-2026 53

intyggar att konstruktion och tillverkning av denna produkt marknadsförd under varumärket PELA

Maskin: Skivhiss för gipsplattor
Typbeteckning: 570-0301
Artikelnummer: 498030

följer alla relevanta bestämmelser i enlighet med Maskindirektivet (MD) 2006/42/EC.

För att tillmötesgå ovan nämnt direktiv har följande harmoniserade standarder använts:

Standard:

EN ISO 12100:2010

Notified body: Ente certificazione machine Srl (ECM)
Certifikatsnummer: 1P170322.H&H0W60

Denna produkt var CE märkt år: 2019


Person som är behörig att ställa samman den tekniska dokumentationen, och är etablerad i Europeiska gemenskapen:

Namn: Lars Edwardsson
Adress: Källbäckstrydsgatan 1, SE-507 42 Borås, Sweden

Denna deklaration gäller uteslutande för produkten i det utförande den placerades på marknaden och exkluderar komponenter som tillförs nu och/eller vid senare tillfälle av slutkunden.


Stad och land: Borås, Sverige

Datum: 10/12/2019



Namn: Ted Berglund
Befattning: Inköpskoordinator

VERKTYGSBODEN



Contact

PELA Tools
Solångsvägen 13
SE-513 70 Borås
Phone: 033-202650
E-mail: order@pelatools.com

Environmental protection / Scrapping

Recycle any unwanted material, do not throw it in the household rubbish. All machines, accessories and packaging must be sorted and left at a recycling center and disposed of in an environmentally friendly manner.



Specifications

Max. drywall size 1220x4880mm
Max weight 70 kg
Max lift height 3150mm
Load height 1800mm
NW / GW 27/29 kg

Unpacking

Once the machine has been unpacked, check that all parts are included and that no parts are visibly defective.

Environmental requirements for installation


The place where the drywall lifter is to be mounted must meet the following:

- Flat, horizontal and stable floor, preferably in concrete or covered with tiles.
- Sufficient space must be around the machine to facilitate use.
- Proper lighting.
- Service and repair of the machine must be performed by a qualified service workshop.


Assembly

The drywall lifter requires easy installation before use. It is important that you read the entire manual to familiarize yourself with the product before using the turntable. Before mounting the drywall lifter, make sure that you have all the parts described in the exploded view.

1. Unscrew the nuts (7 #) from the 5 wheels (6 #). Pass the thread on the wheels through the holes pre-drilled in the arms (2 #). Screw back the nuts and tighten securely.




2. Insert the pre-assembled telescopic tube (8 #) into the hole in the foot (1 #).



3. Screw together the lifting platform. Start by unscrewing the screws (22 #) the profile tube (19#). Screw the side pipes (20 #) in the profile tube (19 #) using the screws (22 #).



4. Mount the lifting platform. Remove locking pin (21 #) and insert the lifting platform (19 #) into square tubes (9 #). Replace locking pin (21 #). Check that the locking pin is locked in the groove in the lifting platform (19 #).




Use

1. Place the drywall on the lifting platform. Make sure it is as centered as possible.
2. Move the panel lift so that it is below the place where the panel is to be mounted in the ceiling.
3. Rotate the control wheel clockwise (18 #) to hoist the disc towards the ceiling. The disc lift is equipped with a latch that goes in every centimeter when you raise the lifting platform. If the control wheel should be accidentally released during hoisting, the latch enters and stops the disc from falling down.
4. When the disc is lifted to the desired height, release the control wheel carefully and make sure that the latch goes in.
5. Screw the board to the ceiling.
6. Lower the lifting platform by pressing safety

catch upwards and rotate the wheel counterclockwise. Do not release the wheel so that the lifting platform collapses and damages the telescopic tube.

Maintenance

1. Lubricate the chain, sprocket and interior of the telescopic tube with grease.
2. Regularly lubricate the control wheel and the foot bushing with lubricating oil.
3. Store the drywall lifter in a dry environment.



Part no.	Description	QTY
1	Base	1
2	Support arm	5
3	End cap	9
4	Bolt M10x45	5
5	Nut M10	5
6	Universal wheel	5
7	Nut M12	6
8	Outer tube	1
9	Inner tube	1
10	Chain	1
11	Screw	6
12	Chain gear	1
13	Chain gear shaft	1
14	Shaft sleeve	2
15	Safety bracket	1
16	Bolt M8x60	2
17	Nut M8	3
18	Handle wheel	1
19	Top bar	1
20	Side tube	1
21	Spring pin	1
22	Bolt M6x35	4
23	Pin 6mm	1
24	Bolt M8x16	2
25	Spring support	1
26	Spring	1
27	Bolt M8x30	1
28	Hex head wrench 8	1
29	Hex head wrench 6	1
30	Hex head wrench 5	1
31	Washer 12	5
32	Washer 10	10
33	Washer 6	4
34	Washer 16	1

EU Declaration of Conformity

2006/42/EC (MD)

ORIGINAL Declaration of conformity

We, the manufacturer

Company: Verktysboden Erfilux AB
Address: Källbäcksrydsgatan 1, SE-507 42 Borås, Sweden
Telephone number: +46-33-2026 53

Declare under our sole responsibility that the product

Machine: Plasterboard lift
Type designation: 570-0301
Item number: 498030

fulfils all relevant provisions of the 2006/42/EC (MD)

To show compliance with the above Directives the following harmonized standards have been applied:

Standards:

EN ISO 12100:2010

Notified body: Ente certificazione machine Srl (ECM)
Certificate number: 1P170322.H&H0W60

This product was CE marked year: 2019

Person authorised to compile the technical file:

Namn: Lars Edwardsson
Adress: Källbäcksrydsgatan 1, SE-507 42 Borås, Sweden

This declaration relates to the machinery in the state in which it was placed on the market, and excludes components which are added and/or operations carried out subsequently by the final user.

City and Country: Borås, Sverige Date: 10/12/2019



Name: Ted Berglund
Position: Purchasing coordinator

VERKTYGSBODEN

PELA
TOOLS

